

remote installation manager, 20
RIM. *See* remote installation manager

S

SCSI
 selecting modules, 16
shell
 maintenance, 73
software RAID. *See* metadisks
ssh program, 22
strimsh program, 22
striping
 logical volumes, 58
 meta-disks, 59
support for UEFI, 13, 15
swap devices, 64
system backup
 network install, 23
 system installation, 36
system backup disk
 local install device, 42
system backup nfs
 local install device, 43
system installation
 booting, 29
 booting in installation mode, 29
 changing LVM and filesystem settings, 48
 cloning systems, 36
 device, 40
 errors, 70
 install device
 changing, 40
 selecting a remote device, 45
 installing the system, 66
 main menu, 34
 mode, 25
 network install server
 changing, 40, 44
 no-prompt install, 19, 36
 settings, 64, 65
 starting, 67
 UEFI, 36
 verification, 66

system recovery. *See* system installation

T

tape
 autoloader, 41
 network install device, 45
tape boot, 32
tape drive
 remote, 45
text
 encryption key, 38
tftpd, 34
Tivoli. *See* TSM
TSM
 administrative user, 48
 client, 48
 configuration, 46
 server, 48

U

UEFI firmware boot, 29
UEFI support, 9
utilities. *See* system recovery utilities
 configure remote install manager, 74
 loading/unloading adapters support, 72
 maintenance shell, 73

V

verify
 hardware configuration, 38
virtual devices
 parallel, 42
 sequential, 42
volume group
 changing install settings, 48
volume groups, 54, 55

Y

yaboot, 65, 68